
Assembly Instructions

Trinity Series





Product Code

TNTY-CST-OAK Trinity Console Table

Dimensions (W x D x H)

1524*368*760mm

Important

Please read through instruction carefully Before assembly and keep for future reference.

For our full catalogue of assembly instructions, Visit: lifely.com.au/assembly.

Important Tips and Maintenance






Keep children and animals away from working area as smaller parts may cause choking if swallowed.



Never place liquids or anything damp upon furniture as it will mark. Ensure a coaster or running is beneath.



3.

Never use ammonia based cleaning products as it will damage the finish.




To avoid fading, keep furniture out of direct sunlight.



5

Use a soft or damp cloth(dry cloth)when wiping or cleaning surfaces.



6.

Two person are required.



7.

Lay a soft matt down to protect the furniture piece before and during assembly. So your relationship is strong. But is it flat-pack furniture strong? Unless you're an aerospace engineer, assembling furniture can be slightly stressful. We recommend meditating quietly, pouring yourself a herbal tea (or slightly less herbal wine) and tackling things one step at a time. If you feel a passive aggressive remark coming on, try a compliment instead. E.g. "You're so good looking."

This 5-step assembly should take around 30 minutes with an Allen key - or 20minutes with an electric drill.

Designed for everyday

Component Hardware

Please check you have all the fittings part or tools are listed in below.

No. A Quantity:12 Pcs Screw M6*20mm



No. G Quantity: 4 Pcs Metal Plate 150*150*2.5mm















No. H Quantity:1 Pc Key 5mm


Component Panels & part List


Please check you have all the panels are listed below.

- 1. Top Panel-----x1 CTN 2/2
- **2.** Leg-----**x**6 CTN 1/2

















TOPPLING FURNITURE WARNING:

- It is strongly recommended that this product is permanently fixed to the wall.
- Please seek professional advice if you are in doubt of what fixing device to use.
- Regularly check that anchors are securely maintained.
- Stability of tall items may be affected by thick pile carpet or uneven floors.
- Do not place unanchored televisions on furniture.

CAUTION: for your safety when attaching the anchor fixings, please note the following:

 Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).



WARNING: PLEASE SECURE YOUR FURNITURE WITH THE SUPPLIED WALL FIXING. SCAN THE CODE FOR MORE INFORMATION.



lifely.com.au
Great job. You're done!
Don't forget to share how it looks in
your space and tag us on Instagram.
@lifelyhome #homewithlifely!