


Assembly Instructions

Tate Series



Lifely*

Product Code

TATE-ED120-OAK-WHT

Tate electric height adjustable desk

Dimensions(W x D x H)

1200×590×(780~1200)mm

Important


Please read through instruction carefully
Before assembly and keep for future reference.

For our full catalogue of assembly instructions,
Visit: lifely.com.au/assembly.

Important Tips and Maintenance




1. Keep children and animals away from working area as smaller parts may cause choking if swallowed.




2. Never place liquids or anything damp upon furniture as it will mark. Ensure a coaster or running is beneath.




3. Never use ammonia based cleaning products as it will damage the finish.



4. To avoid fading, keep furniture out of direct sunlight.



5. Use a soft or damp cloth (dry cloth) when wiping or cleaning surfaces.




6. Two person are required.



7. Lay a soft mat down to protect the furniture piece before and during assembly.

Height Adjustment Controller Operation



Up key



Down key

When the desk does not work normally, suggest following below tips:
Reset your desk by holding the down key  for 5 seconds until the manual controller make a "beep" sound which means finish reset.
Check and re-enjoy your desk.
If reset progress still does not work, unplug the power supply, wait for 5~10 minutes, then press the up key  or down key .

So your relationship is strong. But is it flat-pack furniture strong? Unless you're an aerospace engineer, assembling furniture can be slightly stressful. We recommend meditating quietly, pouring yourself a herbal tea (or slightly less herbal wine) and tackling things one step at a time. If you feel a passive aggressive remark coming on, try a compliment instead. E.g. "You're so good looking".

This 8-Step assembly should take around 60 minutes with an Allen Key or 45 minutes with an electric drill. Godspeed.

Designed for everyday

Component Hardware

Please check you have all the fittings
part or tools are listed in below.

No. A
Quantity: 10Pcs
Screw M6*12mm



No. B
Quantity: 6Pcs
Screw M6*15mm



No. C
Quantity: 8Pcs
Screw M6*20mm



No. D
Quantity: 2Pcs
Screw 4*16mm



No. E
Quantity: 1Pc
Allen Key M6



No. F
Quantity: 1Pc
Controller



No. G
Quantity: 1Pc
Power Supply



No. H
Quantity: 1Pc
Plug




No. I
Quantity: 2Pcs
Wire clip




Component Panels & part List

Please check you have all the parts
are listed below.

- | | | |
|---------------|-------|------------|
| 1. Left leg | ----- | Carton 2/2 |
| 2. Right leg | ----- | Carton 2/2 |
| 3. Table foot | ----- | Carton 2/2 |
| 4. Beam | ----- | Carton 2/2 |
| 5. Side wing | ----- | Carton 2/2 |
| 6. Drive rod | ----- | Carton 2/2 |
| 7. Top | ----- | Carton 1/2 |



STEP 1




No. C
Quantity: 8Pcs
Screw M6*20mm



No. E
Quantity: 1Pc
Allen Key M6




STEP 2



No. A
Quantity: 6 Pcs
Screw M6*12mm



STEP 3



No. A
Quantity: 4 Pcs
Screw M6*12mm



STEP 4




Before assembling, you need to unscrew the screw.


Please read this note carefully before this step:

Insert the left end of the drive rod ⑥ into the hexagon bar of the left leg ① to the position shown in the right figure,
Insert the right end of the drive rod ⑥ into the hexagon bar of the right leg ② to the position shown in the right figure,
Ensure the left end and right end of the drive rod can be tighten WITHOUT TURNING.

PLEASE DO NOT TURN THE DRIVE ROD BY HAND WHEN THE DRIVE ROD INSERT INTO THE HEXAGON BAR OF THE LEGS.




STEP 5



No. B
Quantity: 6Pcs
Screw M6*15mm



STEP 6




No. F
Quantity: 1Pc
Controller



No. D
Quantity: 2Pcs
Screw 4*16mm



STEP 7



No. F
Quantity: 1Pc
Controller





No. G
Quantity: 1Pc
Power Supply



No. H
Quantity: 1Pc
Plug



STEP 8



The way to use the wire clip:

First, you need to tear off the paper on the double-sided tape at the bottom, and then stick it to the position where you need to tie the wire.

Second, thread the line through the wire clip, and then press the wire clip down according to the arrow in the figure to lock it.

lifely.com.au

Great job. You're done!

Don't forget to share how it looks in
your space and tag us on Instagram.

@lifelyhome#homewithlifely!